


USER INSTRUCTION



Auto Tracking Mini IR Speed Dome Camera

Copyright(c)2014(V1.0 Edition)

Special Declaration

Before connecting and using this device, please read this manual carefully and properly preserved for reference in the future.

This manual may contain some inaccurate place in technology, or some printing error. The contents of this manual will update from time to time, but without notice if there is any upgrades; Update contents will be added in new version manual. We will improve or update the product or program of this manual at any time.

Careful Transport

During transport, custody and install process should prevent weight, severe vibration and soak damage to product.

Do Not Disassemble Zoom Camera

In order to well match night vision, we sell IR speed dome camera with zoom camera, please not disassemble zoom camera if there is no technical person.

Power Supply, Video Cable and Control Cable

For power supply cable, video cable and control cable, please adopt shielded cable and independent wiring, can not mix with other cables.

Electric Safety

Should obey all kinds of electric standard when using speed dome camera, make sure signal cable keep enough distance(at least 50m)with high voltage equipment or cables. If it is possible, please take lightning and surge measurement.

Clean

When clean camera housing, please use dry soft cloth to wipe, If it is too dirty, please use neutral cleaner to wipe lightly. Do not use strong or grind cleaner to prevent its housing from scratching.

Strictly Sealed

Prevent liquid or other things get into speed dome housing, else it will cause permanent damage.

Please do not use camera beyond limited temperature and humidity

Speed dome camera working temperature : -25°C to 50°C, humidity less than 90%.

Please do not install camera near air conditioner's outlet

Under following situation, lens will be fogged because of condensation:

*Use under the environment where the temperature rise and down frequently which caused by the air conditioner power on and off frequently.

*Use in environment which can make glass fog.

*Use in environment full with smoke or dust.

Please do not make camera toward to strong light source, such as the sun

Toward camera to strong light source for a long time will damage the color filter on CCD, then it will make image lose color.

| | |
|---|-----------|
| Chapter 1 Product Overview | 3 |
| 1.1 Product features | 3 |
| 1.2 Function Instruction | 4 |
| 1.3 Speed dome Parameter..... | 5 |
| 1.4 Structure Dimension..... | 6 |
| Chapter 2 Installation..... | 8 |
| 2.1 Install Instruction | 8 |
| 2.2 Install Method..... | 8 |
| 2.3 Baud Rate Setup | 10 |
| 2.4 ID Setup | 10 |
| 2.5 Power Supply And Control Cable Connection | 11 |
| 2.6 Connecting Method..... | 11 |
| 2.7 Typical Application Wiring Diagram | 12 |
| Chapter 3 Basic Operation..... | 13 |
| 3.1 Powe-on Self-test..... | 13 |
| 3.2 Preset Setup | 13 |
| 3.3 Call a Preset | 13 |
| 3.4 Preset Function Table | 14 |
| Chapter 4 Menu Setup..... | 17 |
| 4.1 Menu Setup Topology | 17 |
| 4.2 Main Menu..... | 19 |
| 4.3 System Information Menu | 20 |
| 4.4 Display Setting Menu | 20 |
| 4.5 System setting menu | 21 |
| 4.6 Infrared Light Setting | 26 |
| 4.7 Re-start Camera..... | 26 |
| 4.8 Recover factory setting..... | 26 |
| Chapter 5 Appendix | 27 |
| 5.1 FAQs..... | 27 |
| 5.2 Clean the transparent cover | 27 |
| 5.3 Lightning and Surge protection | 28 |
| 5.4 RS485 bus wiring | 29 |

1.1 Product Feature

Strong Intelligent Function

- PELCO-D/P, Hikvision, Dahua and other control protocol auto diagnosis.
- 2400.4800,9600 baud rate auto diagnosis.
- Support graphics drawing menu display.
- Support auto tracking function.

Strong Horizontal and vertical rotation control Function

- Max 200° /s high speed rotate function.
- Vector driver technology, ensure P/T function finished in the shortest route, making video image preview more comfortable.
- Precision stepping motor subdivision technology, speed dome's lowest rotate speed reach 0.6 degree per second. Under high zoom situation, can move image more accurately and stably.

Preset, Track Scanning, Area scanning and more

- Can set up to 220 pcs preset, each preset contain lens zoom and angle position and so on.
- Can record and display up to 4 group track scanning route, each group max can contain 100 movements.
- After set defined area left and right boundary, speed dome camera can move with defined speed in this area.
- Call defined special preset, can come true continuous pan scan.

OSD English Menu

- Built in English/chinese menu, through menu to display and change speed dome parameter.
- Pan/Tilt angle, zoom ,preset all can be display on screen.

PTZ Control

- Adopt RS485 communication protocol.
- Pan 0-360 degree continue rotate, tilt 0-90 degree with auto flip, no monitor blind spot.
- 0.6°-200° in pan speed,0.8°-75°in tilt speed,the speed can be adjusted automatically according to the lens zoom.

1.2 Function instruction

Address Code Setup

Any operation commands has its own target speed dome camera address code, baud rate and control protocol, single camera only response the operation commands corresponded the same address code, baud rate and control protocol. This IR high speed dome camera's baud rate, control protocol will be identified automatically by system.

Focus length/Rotate speed auto match technology

When manual adjust, as to long focus length situation, due to the high speed of speed dome camera, even touch joystick lightly will also make image move quickly. Based on human design, IR high speed dome camera can adjust its speed in pan and tilt automatically according to focus length far or near, making manual follow target more simple and easy.

Auto Flip

When operator controls the lens toward the bottom and still press the joystick, at this time lens will auto flip 180 degree then up flip 90 degree, can monitor the back side image directly, which can achieve 180 degree whole continue monitoring.

Set and Call Preset

Preset is a certain position of speed dome camera which includes ptz's pan angle, tilt angle and camera lens focus and other position parameter, when need speed dome camera go to the certain position, call the certain preset directly which saved in the memory. Operator can save and call preset through control keyboard, IR controller and other control equipment faster and easier. This speed dome camera support 220pcs presets.

Lens Control

(1) Focal Length Control

User can adjust focal length far and near through control keyboard or matrix to get needed image or subtle view.

(2) Focus Control

When system is in auto focus mode, camera lens will auto focus at the middle of view image to keep clear image when zoom changed; under special situation user can manual focus to achieve needed image vision. Under manual focus mode, if need to back to auto focus mode, only need to move joystick or send a special control command or call any preset.

Iris Control

User can adjust the camera's iris through control keyboard and manual adjust to get needed image brightness.

Night vision Function(Color/Black-white change)

Camera has built-in night vision function, under auto color/black-white mode will change CCD illumination according to the change of environment brightness. For example: in daytime because of enough brightness, using common illumination can guarantee color image. But in the night it will change into low illumination to show clear view with black-white mode.

Auto patrol

Put some presets as a group in a certain sequence, it will run this patrol continuously when speed dome camera is in idle mode.

Mode Scan



Mode scan is through menu to save speed dome tracking route, it will run this mode scan continuously when speed dome camera is in idle mode

1.3 Speed dome camera parameter

| Electric | | | |
|------------------------|---------------------------------------|----------------------|----------------------------------|
| Rated Voltage | DC12V/2A | Power | Max 20W |
| Decoder | Built in | IR distance | 40-60m |
| Set | | | |
| Communication protocol | PELCO-D/P HIK/DAHUA | ID | 1-255 |
| Baud rate(RS485) | 2400/4800/9600bps/auto identify | | |
| Operate | | | |
| Pan rotate | 360 endless | Tilt rotate | 90 degree, auto flip |
| | | Preset | 220 |
| Speed | Pan 0.6°-200°/s Tilt 0.8°/s-75°/s | Monitor mode Preset. | patrol,pan scan and pattern scan |
| Environment | | | |
| Operate environment | Outdoor: -20℃~60℃ Indoor: -10℃~50℃ | environment humidity | 0-95% without condensation |
| IP Grade | IP66 | | |
| Physical | | | |
| Installation mode | Wall/ceiling mount | | |



1.4 Structure Dimension

K Type Speed Dome Dimension





Unit:mm

R Type Speed Dome Dimension





Unit:mm

Bracket Dimension Wall Mount Bracket





Unit:mm

Ceiling Bracket



Unit:mm

Lifting bracket



Unit:mm

Chapter 2 Installation

2.1 Install Instruction

Prepare before installation


In order to prevent troubles, installation should be done by professional staff base on corresponding rules.

Confirm all spare-parts are complete, ensure application of this speed dome camera and installation mode is suitable to requirement.


Wall/ceiling mount speed dome composite with bracket, zoom camera, transparent cover and other parts.

All tests have been done before leaving factory, user can directly install and use it.

2.2 Installation Method





Wall Mount Bracket



Ceiling Mount Bracket

Step 1-Draw positioning holes



Take out bracket from package box, mark the holes' position based on bracket bottom installation holes.





Step 2-Drill holes and put expansion screws in

Drill expansion screw's installation holes at pre-marked position, then put expansion screws in. (Note: Please bring expansion screws own.)


K.




R.




Step 3- Open DIP switch blanks, set DIP address (please refer to the third part of this chapter). Install DIP blanks after setting address.



Wall Mount Bracket






Ceiling Mount Bracket



Lifting Mount Bracket

Step 4- Lead cable through the bracket and fix the speed dome camera. Lead cable through the bracket, fix the 4 installation holes of speed dome camera bracket to the 4 pcs expansion screws of wall/ceiling, tighten these 4 pcs nuts. Then sealed the cable via glass glue.




Step 5- Cable connection

Please refer to the sixth section of this chapter-Connection method.

Chapter 2 Installation


2.3 Baud Rate Setup

Baud rate and corresponding DIP status as bellow:




RS485 control bus need all device which connect to it shall be in parallel mode, and each end of the system shall be connected to a 120Ω resistor. Our speed dome has a 120Ω resistor in it, you need only set it up through dip switch SW2, put the 4th switch on, then the resistor is connected, details as below:

resistor is connected




resistor isn't connected



2.4 ID Setup

ID setup (address code setup obey binary rules)
address code shall be set through 8 DIP switch (SW1).

Keyboard control speed dome through communication bus, one keyboard can control max. 255pcs speed dome camera, each speed dome camera has its own address code, user can set address code through 8 DIP switch, details as bellow:



| Address | SW1 Switch Setup | | | | | | | |
|---------|------------------|-------|-------|-------|-------|-------|-------|-------|
| | SW1-1 | SW1-2 | SW1-3 | SW1-4 | SW1-5 | SW1-6 | SW1-7 | SW1-8 |
| 1 | ON | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| 2 | OFF | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 3 | ON | ON | OFF | OFF | OFF | OFF | OFF | OFF |
| 4 | OFF | OFF | ON | OFF | OFF | OFF | OFF | OFF |
| 5 | ON | OFF | ON | OFF | OFF | OFF | OFF | OFF |

| | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 6 | OFF | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 7 | ON | ON | ON | OFF | OFF | OFF | OFF | OFF |
| 8 | OFF | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 9 | ON | OFF | OFF | ON | OFF | OFF | OFF | OFF |
| 10 | OFF | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 11 | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |
| 12 | OFF | OFF | ON | ON | OFF | OFF | OFF | OFF |
| --- | --- | --- | --- | --- | --- | --- | --- | --- |
| 254 | OFF | ON | ON | ON | ON | ON | ON | ON |
| 255 | ON | ON | ON | ON | ON | ON | ON | ON |

2.5 Power supply and control cable connection

Power supply connection

Note: Please check rated voltage and power supply carefully, rated voltage and current as bellow:

| rated voltage | rated voltage range | current |
|---------------|---------------------|---------|
| DC12V | $\pm 10\%$ | 2A |

Control line connection

Connect RS485 line to keyboard controller or DVR, if there are more than one need to be controlled by keyboard or DVR, please connect it in parallel.


Note: (1) Protocol and baud rate of keyboard and DVR can be set by customer, just make sure it is same with that of speed dome.

(2) The ID of different speed dome which is in same system shall be set as different.

2.6 Connection Method

Connection method as bellow diagram, connect video cable, control cable, power supply cable in turn. Connection method of keyboard can refer to keyboard manual (connection cable order based on keyboard model, here only provide one possible example), detail please refer to bellow diagram:


Chapter 2 Installation



DC12V connection details:

| Port mark | Port instruction | Cable color/type | Connection instruction |
|------------|-------------------|------------------|------------------------------------|
| Power line | DC12V input port | DC connector | Connect to DC12V power supply |
| RS485A | RS485+ | white | Connect to RS485+ |
| RS485B | RS485- | green | Connect to RS485- |
| Video line | Video output port | BNC connector | Connect to monitor or other device |

2.7 Typical Application Wiring Diagram



Because different system platform's specific operation method is not totally same, generally subject to manufacturer's manual, different situation has special requirements and operation method. Please contact distributor to obtain necessary information. Hereby only introduce control method when it connect to universal keyboard controller.

3.1 Power-on Self-test

After power-on speed dome camera, it will action in pan and tilt direction automatically. Through self-test to confirm speed dome camera working normally.

Control speed dome camera up, down, left and right rotate:

After select one camera, can manual control speed dome camera's up, down, left and right movements through keyboard joystick. Rocking of joystick control camera action, when twist the joystick to right, camera will also move to right, similarity, when twist the joystick to left then camera will also move to left. When twist joystick in tilt direction, camera also will make corresponding action in tilt direction. When twist joystick in diagonal direction, can make camera make pan and tilt direction action at the same time, and the movement direction same as joystick.

3.2 Preset Setting

Operation steps as below:

- (1) Select camera (please refer to keyboard controller manual for details)
- (2) Operate joystick or zoom+/- button to adjust camera image;
- (3) Press (PRESET) + (N) (input specified preset number) + (ENTER), save current position parameters as a preset.

3.3 Call a Preset

Operation steps as below:

- (1) Select camera;
- (2) Press (SHOT) + (N) (input specified preset number) + (ENTER), camera move to corresponding preset position at once, zoom+/- will also adjust according to the parameter of preset automatically.

Chapter 3 Basic Operation

3.4 Function Realization By Preset

Adopting the method of double-layer presets, achieve all the functions of the camera by preset call, Specific correspond <<Preset Function Table of General Function>> and <<Preset Function of Specific Function>>.

Call mode: call mode is on in general preset of call, specific function is achieved by the mode of preset call; for example: [92] + [SHOT] + [1] + [SHOT], which is to call patrol 1;

Setting mode: setting mode is on in general preset of setting, specific function is achieved by the mode of preset call; for example: [92] + [PRESET] + [1] + [SHOT], which is to set patrol 1.

Preset Function Table of General Function


| General Function | Preset |
|----------------------|--------|
| IR | 90 |
| Zoom module | 91 |
| Patrol scan | 92 |
| Pattern scan | 93 |
| PTZ control | 94 |
| Menu | 95 |
| System Setting | 96 |
| Reservation | 97 |
| High speed auto scan | 98 |
| Low speed auto scan | 99 |

Preset Function Of Specific Function

| General Function | Preset No. | Call Mode | Setting Mode |
|---------------------|------------|---------------------------------|------------------------|
| IR Function | 1 | Auto ON/OFF | |
| | 2 | Forced ON | |
| | 3 | Force OFF | |
| | 11 | High Sensitivity | |
| | 12 | Middle Sensitivity | |
| | 13 | Low Sensitivity | |
| Zoom Module Setting | 1 | IRCUT - ON | |
| | 2 | IRCUT - OFF | |
| | 3 | IRCUT - AUTO ON | |
| | 4 | IRCUT - AUTO OFF | |
| | 50 | Zoom Camera Automatic Diagnosis | |
| | 51 | SONY | |
| | 52 | HITACHI | |
| | 53 | SAMSUNG | |
| | 54 | HIK | |
| | 55 | MYTECH | |
| | 56 | LG | |
| | 57 | LG-XDI | |
| | 58 | CNB | |
| | 59 | CNB 36 x Optical Zoom | |
| | 60 | GV | |
| | 61 | SWELL | |
| | 62 | BQL | |
| | 63 | WIT | |
| | 80 | Enter module menu | |
| Patrol Scan | 1 | Call patrol 1 | Patrol 1 setting start |
| | 2 | Call patrol 2 | Patrol 2 setting start |
| | 3 | Call patrol 3 | Patrol 3 setting start |
| | 4 | Call patrol 4 | Patrol 4 setting start |

| | | | |
|----------------|--------------------------|--------------------------------|-------------------------|
| Patrol Scan | 5 | Call patrol 5 | Patrol 5 setting start |
| | 6 | Call patrol 6 | Patrol 6 setting start |
| | 7 | Call patrol 7 | Patrol 7 setting start |
| | 8 | Call patrol 8 | Patrol 8 setting start |
| | 9 | Patrol setting end | |
| | 10 | Patrol time setting(5-240sec.) | |
| | 11 | Patrol speed setting(1-63) | |
| Pattern Scan | 1 | Call pattern 1 | Pattern 1 setting start |
| | 2 | Call pattern 2 | Pattern 2 setting start |
| | 3 | Call pattern 3 | Pattern 3 setting start |
| | 4 | Call pattern 4 | Pattern 4 setting start |
| | 5 | Pattern setting end | |
| PTZ Control | 1-8 | Park preset 1-8 | |
| | 9-16 | Park patrol 1-8 | |
| | 17-20 | Park pattern 1-4 | |
| | 21 | Park auto scan | |
| | 22 | Park AB lines scan | |
| | 30 | Park time 0(off) | |
| | 31 | Park time 10s | |
| | 32 | Park time 30s | |
| | 33 | Park time 60s | |
| | 41 | A line-scan setting | |
| | 42 | B line-scan setting | |
| | 43 | High speed line-scan start | |
| | 44 | Middle speed line-scan start | |
| | 45 | Low speed line-scan start | |
| | 46 | Inner arc line-scan | |
| | 47 | Outer arc line-scan | |
| | 50 | Open the automatic tracking | |
| | 51 | Turn off automatic tracking | |
| System Setting | Continuous call 10,12,14 | Restore factory settings | |

4.1 Menu Setup Topology



Chapter 4 Menu Setup

This Chapter will introduce the OSD menu operation in detail. PTZ self-test when power up, it will display the following information on the monitor.

| | |
|-------------------------|------|
| Control Protocols: | Auto |
| Serial Port info: | Auto |
| PTZ hard address : | 1 |
| PTZ soft address: | 1 |
| PTZ soft address enable | Off |
| CCD Type: | HIK |

Due to the PTZ operation is not complete the same based on different surveillance system, for the detail operation, please contact with distributors. Below is the general introduction of the basic operation of the keyboard control to the OSD menu.

Enter OSD main menu

SHOT 95 , enter OSD main menu. 【OPEN】 (IRIS open) is confirm button, 【CLOSE】 (IRIS close) Exit the menu.

Enter other Menu

Up/down move the joystick to make the cursor point to a certain menu, press 【OPEN】 button, enter menu.

Function Select

Up/down move the joystick to make the cursor point to a certain function, press 【OPEN】 button, select the function.

Parameters Select

Up/down move the joystick, select the parameter, press 【OPEN】 button, save the parameters.

Save setting

Press 【OPEN】 button, save the parameters, it is valid under the presentation.

Un-save Setting

Back to the last menu: press 【Close】 button, back to the last menu, it is valid under the tips.

Exit Menu

Up/down move the joystick to make the cursor point to the "Exit" option, then press 【OPEN】 button, Exit the OSD Menu.

4.2 Main Menu

After the PTZ powered up and work normally, SHOT 95, enter main menu, the monitor displayed as below diagram 4.1.




diagram 4.2 Main Menu

The explanation of each option in Main Menu

<System information > : Display system information menu

<Display setting> : Screen information display the time

<Infrared light setting>: set the setting of PTZ

<Restart camera> : Re-start the zoom module

<Restore factory setting>: All the parameters revert to Windows default

< Exit> : exit the OSD menu

Chapter 4 Menu Setup

4.3 System Information Menu

To check the basic information of the PTZ.

| | |
|------------------------------|----------|
| System information | |
| Communication protocol : | PELCO D |
| Communication Baud rate: | 2400 |
| Hard address | 1 |
| Soft address | 1 |
| Soft address enable | OFF |
| Speed dome inner temperature | 30℃ |
| Software version | 0F140328 |
| Language | English |
| Exit | |

diagram4.3 System information menu

The explanation of each option in System Information

<Communication protocol> : Display the serial port of communication protocols of the PTZ.

<Communication Baud Rate>: Display the communicate speed of the PTZ.

<Hard address>: Display the hardware tip address : 1-255

<Soft address>: Display the soft address: 1-255

<Soft address enable>: Display if the soft address of the ptz can use

<Speed dome inner temperature: Display the inner temperature of the PTZ

<Software version>: Display the software Version that used.

<Language>: display the current language,English & Chinese selectable

<Exit>: Exit the menu

Remark: Each options in the System information menu can not be modified.

4.4 Display Setting Menu

| | |
|---------------------|---|
| Display Setting | |
| Information tips(S) | 3 |
| PTZ display (S) | 3 |
| Alarm display (S) | 3 |
| Exit | |

diagram4.4 Display setting menu

The explanation of each option in Display setting menu

. Information Tips (S) : The screen will display the time when operate the PTZ

.PTZ display (S): will display the time when operate the PTZ.

4.5 System Setting Menu

| System Setting | |
|------------------|---|
| Camera | > |
| Movement control | > |
| Preset | > |
| Patrol track | > |
| Modes Scan | > |
| Alarm | > |
| Clear | > |
| Exit | |

diagram4.5 System Setting menu

4.5.1 Camera

< Camera> : to set the parameters of the zoom module, select enter.

| Camera | |
|--------------------------|------|
| Screen Tips | Off |
| Auto Color turn to black | On |
| Auto Focus | On |
| Focus speed | Fast |
| Digital Zoom | On |
| Zoom Rate | Fast |
| Exit | |

diagram4.5.1 Camera

The explanation of each option in Camera Menu.

<Screen Tips > : Whether open the inner tips of the Zoom module.

<Auto Color turn to black > : Whether open the auto color turn to black function.

<Auto Focus > : Whether open the Auto Focus function

<Focus speed > : Set the Focus speed of the zoom module

<Digital Zoom > : Whether open the Digital Zoom function of the zoom module.

<Zoom Rate > : Set the Zoom rate of the Zoom module.

Chapter 4 Menu Setup

4.5.2 Motion Control

<Motion Control> : To set the Motion parameter of the PTZ, and enter.

| Motion Control | |
|----------------------|----------------|
| Auto flip | On |
| Telephoto Speed | On |
| Park action time (S) | No |
| Park Executive | No |
| Running Executive | No |
| Manual Speed | High |
| Lines scan settings | |
| Line scan methods | within the arc |
| Scan speed | Medium |
| Limit Stop | Off |
| Limit Settings | |
| The North Settings | |
| Exit | |

diagram 4.5.2 Motion Control

The explanation of each option in Motion control Menu

<Auto flip> : The PTZ Auto flip 180 degree when the PTZ down to lowest point.

<Telephoto Speed > : PTZ decrease the speed automatically according to the digital zoom.

<Park action time (S) > : To set the Park action time

<Park Executive > : To set the Park action

<Running Executive > : Set the menu when powered on, it will auto execute before the PTZ receive the commend after powered on.

<Manual Speed>: To set the speed of the PTZ.

<Lines scan settings>: To set the line scan between A and B position

<lines scan methods>: Select line scan methods

<lines scan speed > : To set the line scan speed

<Limit Stop > : Whether open limit stop function

<Limit Settings > : To set the up down left and right limit point

<the North Settings > : To set the North setting.

4.5.3 preset

<Preset> : execute the operation of the Preset, enter.




diagram 4.5.3 preset

The explanation of each option in Preset Menu

<Number> : Select the No. Of the preset, 1-220 is valid

<Label> : This option is default, can not be modified.

<Edit>: Set the position of the selected Preset.

<Remove>: Remove the selected Preset

4.5.4 Patrol Track

<Patrol Track> : Execute the operation of Patrol track, enter




diagram 4.5.4 Patrol Track

The explanation of each option in Patrol track menu.

<Number> : Select the No. Of the Patrol , 1-8 is valid.

<Edit>: Set the information of the Patrol track

<Preview>: Preview the Patrol track

<Remove>: Remove the selected Patrol track

4.5.5 Mode Scan

<Mode Scan> : Execute the operation of the Mode Scan, enter.




diagram 4.5.5 Mode Scan

Chapter 4 Menu Setup

The explanation of each option in Mode Scan menu.

<Number>: Select the No. Of the Mode Scan, 1-4 is valid

<Edit> : Edit and record the path of the selected Mode Scan

<Preview> : Preview the selected Mode Scan

<Remove>: Remove the selected Mode Scan

4.5.6 privacy mask

<Privacy Mask> : Execute the operation of the Privacy mask, enter.




diagram 4.5.6 privacy mask

The explanation of each option in Mode Scan menu.

<Number>: Select the No. Of privacy mask zone

<Edit> : Edit and record the path of the selected privacy mask zone

<Remove>: Remove the selected privacy mask zone

About the setting of privacy mask

Privacy mask function need the zoom module's support, only Sony and Samsung zoom module support privacy mask function, Sony zoom module support 24 privacy mask zone, Samsung zoom module support 8 privacy mask zone.

Find the privacy mask item from system setting menu, get into privacy mask item through pressing Iris+ or move joystick toward right., select the privacy mask zone number and move to 'edit' item, press 'Iris+' to edit it.

Two steps to edit the privacy mask zone, move the speed dome toward the target which need to be masked, there is a red area at the center of the screen, press 'Iris+' to second step, it will prompt to adjust the mask area, you can through moving joystick up/down/left/right to adjust the red area size, till it cover the target area which need to be masked, press 'Iris+' to save, the red area will change its color to gray, setting is finished.

During setting, press 'Iris-' will quit edit mode, and present mask area will be removed. The sub-item 'remove' can delete the mask zone which is selected.

4.5.7 Auto Tracking

<Auto tracking>: Perform auto tracking related operations, choose to enter.




diagram 4.5.8 Alarm

The explanation of each option in Auto Tracking menu.

<Open tracking>: Auto tracking switcher.

<scene setting>: Set the monitor scene, select the sensitive area. If set the sensitive area, the moving objects in the non-sensitive area will not trigger tracking; if not set the sensitive area, then all the moving objects in the view will trigger tracking

<Adaptive zoom>: Set the speed dome camera whether automatically adjust the zoom during tracking, in order to monitor the moving objects better.

<Sensitivity>: Set the speed dome camera moving angle when tracking, the value larger speed dome camera moving angle much larger

<Return Time>: Set the time when speed dome camera again back to the monitoring point when it track the target to lost.

4.5.8 Remove

<Remove>: Remove the Preset, patrol track, mode scan information.




diagram 4.5.9 Remove

The explanation of each option in Remove menu.

.<Preset>: Remove all the Presets

.<Patrol track>: Remove all the Patrol Track

.<Mode Scan>: Remove all the Mode Scan

Chapter 4 Menu Setup

4.6. Infrared light Setting

Infrared Light Setting Menu

| Infrared light Setting | |
|------------------------|------------|
| IR light control mode | Auto |
| Open IR light Filter | 220 |
| Close IR light Filter | 170 |
| IR lightness mode | power-save |
| Present Filter | 50 |
| Exit | |

diagram 4.6 Infrared light Setting

The explanation of each option in Infrared light Setting menu.

<IR light control mode>: Set the control mode of the IR light, auto, No/Off mode.

<Open IR light Filter > : Set the Filter of open the IR light.

<Close IR light Filter >: Set the Filter of close the IR light

<IR lightness mode > : Set the IR lightness mode, power-save strategy, evenly increase, manual control mode

<Present Filter > : The present filter, 0-255 is valid

4.7. Re-start Camera

Selected this option can decide whether need to restart the Zoom module.

4.8. Recover Factory Setting

Selected this option can decide whether need to recover the PTZ menu parameters, please re-start the PTZ after the recovery.

5.1 FAQs

| Faults Phenomenon | Check part | Probable Cause | Solution |
|--|--|--|--|
| There is no action and no image after powered up | Check power adapter and power PCB | Power adapter | Change power supply |
| | | Power circuit exist has problem | Replace |
| There is image, but do not self-test when powered on | Motor has abnormal sound | Mechanical problem | Overhaul if it get stuck in something |
| | PTZ Swings | Very incline | Set it straight |
| | Power supply | Power is not enough | Change a new power supply that meet the requirements |
| | motherboard | Something wrong with motherboard | replace |
| There is no image, but can do self-test after powered on | Connection line between power panel and connection panel | Do not insert properly | Insert again and push protective cover |
| | Video line, BNC Connector | Do not install contact properly | Make sure all connection is proper |
| There is image, and can do self-test, but can not control after powered on | RS485 communicate line | Something wrong with the circuit | Make sure all connection is proper |
| | N/A | Irregular operation leads to out of control | Power off and restart |
| | | Something is wrong with the motherboard | replace |
| | Check Focus mode | Speed dome camera is in state of manual focusing | Operate speed dome camera or call any one preset to make it back to auto. focusing |
| Video image is Foggy | Transparent cover | Transparent cover is dirty | Clean transparent cover |

5.2 Clean the Transparent Cover

In order to make the image clear, the cover need to be cleared timely.

When clear, please be careful for avoiding to touch the transparent cover directly, the acid sweat of the human finger may rust the surface of the cover. The scratch of the flint to the transparent cover will lead to foggy image, affect the image quality.


Please use soft enough dry cloth or other replacement to wipe the inner and surface.

If seriously dirty, can use neutral cleanser, any high grade furniture cleanser can used to clean the transparent cover.

5.3 Lightning and Surge protection

Outdoor speed dome camera must consider thunder-proof and surge immunity. On the premise of guaranteeing electrical safety, we can take following lightning protection measures:

- Atleast keep 50m distance between signal transmission line and high voltage equipment or high voltage cable.
- Outdoor wiring under the eaves.
- For open field, adopt seal steel pipe buried wiring way, and adopt one-point earthing with the steel pipe. Do not adopt aerial wiring.
- It need to add extra high-frequency thunder-proof device and lightning rod in strong thunderstorms area or high inductive voltage region(such as high voltage substation).
- Thunder-proof and grounding design of Exterior installation and circuit must be in accordance with building lightning proof requirements; It must meet national standard and industry standard.
- System must be equipotential grounding. Grounding device must meet anti-jamming and electric safety dual requirements. The connection with strong electrified wire netting can't be short connection or mixed connection. When system is in the condition of single-phase grounding, ground impedance is less than 4Ω , ground wire cross-section area must be more than 25 mm^2 .



5.4 RS485 Bus Wiring

1. RS485 bus basic characteristic

RS485 industry bus is characteristic impedance 120Ω half-duplex communication bus according to RS485 industry bus standard.

2. RS485 bus transmission distance

When use 0.511mm (24AWG) screen twisted pair cable as communication cable. Depending on different baud rate, the longest transmitting distance theoretical value is shown as below:

The longest transmitting distance of baud rate

2400Bps 1800m

4800Bps 1200m

9600Bps 800m

3. Connection mode and terminal resistance

RS485 industry bus standard require adopt snake-like wiring(chrysanthemum chain), The ends must connect with 120Ω terminal resistance(such as figure 6), ease connection can adopt figure 7, but distance of section "D" can't exceed 7m.





Fig6



006.08.09-64T-R

