



Dental Design Studio Inc.

2312 Bethards Drive, Santa Rosa CA 95405

phone: (707) 568-7680 fax: (707) 568-7667 toll free: (800) 568-9688

email: dds1lab@aol.com website: <http://www.ddslabs.com>

IMPLANT CLOSED IMPRESSION TRAY TECHNIQUE

- 1) Remove Healing Cap.
- 2) Inspect implant prosthetic table for tissue invagination.
- 3) Place the closed tray transfer impression post on the implant prosthetic table with the Hex driver.
- 4) Use an X-Ray to verify that the impression post is completely seated.
- 5) Block out the top of the screw hole with wax.
- 6) Syringe the impression material around the entire impression post. Material can be any medium to heavy body poly vinyl.
- 7) Fill the full arch impression tray with impression material and seat the tray in the mouth.
- 8) Remove after the impression material has set.
- 9) Remove the impression post.
- 10) Replace the healing abutment.