



Dental Design Studio, Inc

2312 Bethards Drive, Suite 4 Santa Rosa, CA 95405
phone (707)568-7680 fax (707)568-7667
toll free (800)568-9688

email: dds1lab@aol.com website: www.ddslabs.com

IMPLANT CLOSED IMPRESSION TRAY TECHNIQUE

- 1) Remove Healing Cap.
- 2) Inspect implant prosthetic table for tissue invagination.
- 3) Place the closed tray transfer impression post on the implant prosthetic table with the Hex driver.
- 4) Use an X-Ray to verify that the impression post is completely seated.
- 5) Block out the top of the screw hole with wax.
- 6) Syringe the impression material around the entire impression post. Material can be any medium to heavy body poly vinyl.
- 7) Fill the full arch impression tray with impression material and seat the tray in the mouth.
- 8) Remove after the impression material has set.
- 9) Remove the impression post.
- 10) Replace the healing abutment.