

Professional Restoration Series

Recommended Procedures For Water Damage

When any trained staff first enters the claim, course spray PRS Water Damage PreClean diluted up to 1:10 with water or assuming there is standing water use PreClean undiluted. Use PRS Water Damage PreClean undiluted if there is already plenty of water. The intensity of the odour and the amount of available moisture will dictate how much PreClean to use and it's concentration. The area of contamination needs to remain visibly moist for 1 hour minimum.

Take one or two 4 Litre jugs to any black water claim. In this application PRS Water Damage PreClean will eliminate odours within the location, liquefy solids in black water, start the organic digestion process in all areas of sustained moisture, as well as minimize the odour within equipment used by contractor.



Water Damage
PreClean

Do your physical cleanup as per IICRC S-500 Guidelines. Extract residual, remove contents and carpets etc depending on type of back up or flood. Pressure clean.

Spray Post Clean up to 1:10 mixed with water to thoroughly wet or moisten all affected areas. Area should remain visibly wet for up to one hour. In this application, PRS Post Clean will follow all moisture to digest any organic loads remaining including those not otherwise accessible to conventional restoration methods.

Start drying process. - 24 to 48 hours later when dryers are being picked up, apply Enviro Chem Neutral Disinfectant using pump up sprayer, as per label instructions with water.

Be sure to wet spray all surfaces to insure 10 minutes wet contact time.



Water Damage
PostClean

Restoration contractors have been achieving exceptional results and reducing call-backs with RML products in all forms of water damage claims. Always work within IICRC Guidelines.



Call Today!
1-800-387-7174



Water Damage