

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Akai	LCT3201AD	T-Con	2320WA01CBC	320WA01C	
Akai	LCT3201AD	Inverter	VK89144.J01	4H.V1448.301/E2	
Akai	LCT3701AD	Main	771S42D102-01	E3761-053020-2	
Curtis	LCD3215A	Power Supply	FSP205-4E03	9OC2050600	
Dynex	DX-LCD32	Audio Board	715T2412-1	715T2412-1	
Dynex	DX-32L150A11	Main	6KS0120110	569KS0169C	
Dynex	DX-L32-10A	Inverter	19.31T03.013	V225-3XX	
Dynex	DX-L32-10A	Power Supply	6KT00120A0	569KT01200	
Emerson	LF402EM6F DS2	Main	A4G2KMMA-001	BA4GU5G0201 4	A4G2K-MMA
Funai	LF320EM4-A	Main	A4AFOMMA-002	BA4AFPG0201-1	
HCT	HLD-320GF	Main	PA-0326-2-11G	LK14DU	
Hisense	F40V87C	Inverter	LJ97-03241A	SSI400-08A01	
Hisense	F40V87C	Power Supply	125372	RSAG7.820.167/ROH	
Hisense	F40V87C	Main	153894	E110315	
Hitachi	L40A105A	Power Supply	CEL713A		
Hitachi	L42S503	Inverter	27-D029469	T871028.14	
Hitachi	L40A105A	Inverter	LJ97-02751B	SSI400-12A01	
Hitachi	L40A105A	Main	CAACI18121	CMK20	
Hitachi	L40A105A	Signal Board	CEK677A		
Insignia	NS-42L260A13A	T-Con	55.42T08.C29	T315HW07	
Insignia	NS-LCD32-09	Main	CBPF8Z5KQ6	715T2830-2	
Insignia	NS-42L260A13A	Main	756TXCCB0ZK0100001	715G5344-M01-000-004K	
Insignia	NS-42L260A13A	Inverter	INTV9QAAAAB8	715G4047-P02-000-003S	
Insignia	NS-39E340A13	LED Driver	160222	L390H1-1EE	
Insignia	NS-LCD42HD	T-Con	996510010061	V420H1-C07	35-D016630
Insignia	NS-42L260A13A	Inverter	INTV9QAAAAB9	715G4048-P02-000-003S	
Insignia	NS-39D220NA16	Main	55.38S01.1E1		
JVC	LT-40X787	Digital Board	SSD-2204A-M2	LCA10727	LCB10727
JVC	LT-40X787	Main	SFL-1312A-M2	SFL-1312A-M2	LCA10710
JVC	LT-40X787	D-Amp	SFL-6302A-M2	LCA90641	SFL-6302A
JVC	LT-40X667	Digital Board	SFL0D189A-M2	LCB10708	
JVC	LT-40X667	DC-DC PWB	SFL-9161A-M2	LCA90651	
JVC	LT-40X667	Inverter	HI40024W2A-R	HI40024W2A	SIT400WD20B00
JVC	LT-40X667	Inverter	HI40024W2A-L	HI40024W2A	SIT400WD20B00
JVC	LT-40X887	Power Supply	SFL-9060A-M2	LCA90643	
JVC	LT-37XM48	Power Supply	SFN-9051A-M2	LCA90716	
JVC	LT-37XM48	Inverter	19.37T04.008	VIT71037.50	
JVC	EM50RF5	T-Con	55.50T15.C11	T420HVN06.3	
JVC	LT-37XM48	Digital Board	SFN-0D501A-M2	LCA10788	
JVC	EM50RF5	Main	3650-0232-0150	0171-2271-5832	
JVC	EM50RF5	Power Supply	0500-0614-0760	PSLL141303MA	
JVC	LT-37XM48	T-Con	55.37T04.C01	T370HW02 V402	
JVC	LT-37XM48	Main	SFN-1501A-M2	LCA10803	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
LG	50LN5750-UH	T-Con	6871L-3256A	6870C-0452A	
LG	50LN5750-UH	Main	EBT62387716	EAX64872104-1.0	EBR76643206
LG	55LV4400-UA	Power Supply	COV31149301	0500-0607-0190	DPS-159CP
LG	47LN5750-UH	Power Supply	EAY62810801	EAX64905501	
LG	47LG50	T-Con	35-D020223	V420H1-C07	
LG	47LG50	Inverter	27-D017521-M	I470H1-20A-Master	
LG	50PG60-AU	Power Supply	EAY41360901	PSPF551601A	LPX55
LG	55LV4400-UA	Main	COV31310901	3655-382-150	0171-2272-4152
LG	60LS5750-UA	Power Supply	EAY62876001-6	EAX62876001-6	
LG	60LS5750-UA	LED Driver	6917L-0101A	KLS-E600DRGHF16	
LG	RM-27LZ250C	Main	3911TKK755E001	6870T802A66	
LG	RM-27LZ250C	Power Supply	6871TPT275A	BT-EFL30180W-A	
LG	42LK451C-UB	T-Con	6871L-2045Q	6870C-0310C	
LG	55LV5300-UA	Power Supply	EAY60908801	LGP4247-10 IOP	
LG	42LD452B-UA	Power Supply	EAY62770801	EAX64743301	
LG	55LV5300-UA	T-Con	EBR61488901	EAX64277102	
LG	42LC2DA-UE	Power Supply	EAY32731102	FSP286-6F02	
LG	60LS5750-UA	T-Con	6871L-3018A	6870C-0425B	
LG	32LG700H	T-Con	6871L-1950A	6870C-0238B	
LG	42LB1DB-EC AEKLLJP	T-Con	6871L-2978A	6870C-0223A	LC420WX5-SLC2
LG	47LG50	Power Supply	EAY40505301	EAX40157601	
LG	47LD450	Power Supply	EAY60869506	EAX61289601/11	
LG	60LS5750-UA	Main	EBR76298401	EAX64434209-1.0	
LG	42LK450-UB CUSYLH	Main	EBR73308802	EAX642905010	
LG	47LG50	Inverter	27-D017521-S	I470H1-20A-Slave	
Magnavox	50MV314X/F7	Main	A4DU1MMA-003	BA37U0G0401	
Magnavox	42MF531D/37	Inverter	60.42T01.007-S	4H.V1838.381/C2	
Magnavox	50MV314X/F7	Power Supply	A4D1BMPW-001	BA4GU5F0101	
Magnavox	37MF321D/37	T-Con	6871L-0801A	6870C-0060F	
Magnavox	37MF321D/37	Power Supply	313815864961	31381036294.3	715T2056-1
Magnavox	42MF231D/37	Main	313815866271	6285.4	715T2053-1
Magnavox	39MF412B/F7 DS1	Power Supply	A21T0MPW-001	BA21T0F01021	
Mitsubishi	LT-37131A	Signal Board	921C534001	211A86201	
Mitsubishi	LT-52144	Power Supply	921C544004	921C544004	
Mitsubishi	LT-37131A	Inverter	RDENC2283TPZT	IM3831T	
Mitsubishi	LT-37131A	Power Supply	921C533003	921C5330	
Mitsubishi	LT-37131A	T-Con	CPWBX3543TPZA	CPWBX3543TPZ	
Mitsubishi	LT-52144	PCB Board	920D743001	920D7430	
Mitsubishi	LT-52144	Main	921C549007	211A93201	
Mitsubishi	LT-52144	Signal Board	920D740002	211A90801	
Mitsubishi	LT-52144	T-Con	LJ94-02097H	46HHC6L3.3	
NEC	L408TM	T-Con	LJ94-02825D	SYNC60C4LV0.3	
NEC	L408TM	Main	9S2NVQ2	J2090521	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
NEC	P401	Power Supply	MPF2932	PCPF0247	
Nsighnia	NS-32E859A11	T-Con	55.31T12.C07	T420HW07 V2	
Nsighnia	NS-32E859A11	Power Supply	56.04124.131	DPS-124DPA	
Nsighnia	NS-32E859A11	Main	55.71V01.A01	09167-1	
Nsighnia	NS-32E859A11	Audio Board	48SWB201.0GA		
Olevia	242-S11	Main	SC0-P605208GMM0	EPC-P605201G000	
Olevia	242-S11	Power Supply	FSP271-4F02 V.3	FSP271-4F02 V.3	
Olevia	226-S13	Main	SC0-P604205G26C	EPC-P604201G000	
Orion	SLED4668W	Digital Board	A12092384	PL.MS6M30.1B-1-11375	
Panasonic	TC-L32X5	Power Supply	TXN/P1RZUU	TNPA5596CJ	
Panasonic	TC-L32X5	Main	TXN/A1RZUS	TNP4G521UA	
Panasonic	TC-L32X5	Main	TXN/A1RZUS	TNP4G521UA	
Philips	42PFL5432D/37	T-Con	V420H1-C07	996510010061	
Philips	42PF5421D/10	Audio Board	310432843895	310431360647	
Philips	42PFL3704D/F7	Inverter	27-D026774	I420H1-16A0	
Philips	52PFL7422D/37	Main	310432852164	310431361962	310430350848
Philips	32MF231D/37	Inverter	6632L-0212D	KLS-EE32CI-M	
Philips	42PFL3704D/F7	Main	A91H9MMA-001	BA94H0G04013	
Philips	32MF231D/37	Inverter	6632L-0212D	KLS-EE32CI-S	
Philips	32MF231D/37	Main	313815866271	55.31T12.C07	
Philips	32MF231D/37	T-Con	6871L-0796A	6870C-0060F	
Philips	42PFL3704D/F7	Power Supply	A91H5MJC-001-JK	BA94H0F01012-A	
Philips	40PFL3705D/F7	T-Con	RUNTK4323TPZZ	CPWBX4323TPZZ	
Philips	32MF231D/37	Power Supply	313815866811	31381036282.1	
Philips	42PF5421D/10	Inverter	6632L-0152A	KLS-420CP-D	
Philips	42PF5421D/10	Inverter	6632L-0151A	KLS-420CP-C	
Philips	40PFL7505D/F7	Power Supply	UPBPSP0SM001	2820A	HPLD460A
Philips	42PFL3704D/F7	Power Supply	A91H9MIV-001	BA94H0F01033-A	
Philips	42PFL3704D/F7	T-Con	35-D025961	V420H1-C12	
Philips	50PF7220A/37	Main	310432834332	310431360378	
Philips	55PFL4909/F7	T-Con	6871L-3674C	6870C-0471D	
Philips	32MF231D/37	Main	313815866881	31381036284.2	
Philips	42PF7421D/37	Main	313926801294	310431360955	
Polaroid	FLM-3232	Main	899-KC0-GF321XA-3H	200-107-JK371CH	
Polaroid	FLM-3232	Inverter	19.26006.166	4H.V1448.291/B1	VK.89144.H02
Polaroid	FLM-3232	T-Con	55.31T03.003	05A30-1A	T315XW02.V0
Polaroid	FLM-373B	T-Con	55.37T02.031	T370XW01V1	
Polaroid	FLM-3232	Tuner	899-D01-JK401XAH	200-107-JK371CBH	P03-D01-JK401X.
Polaroid	TLX-03210B	T-Con	55.31T03.072	T315XW02V9	T260XW02VA
Polaroid	FLM-3232	Main	899-KC0-GF321XA-3H	200-107-JK371CH	
Protron	PLTV-4250	Digital Board	07113250-R0600	F51-670024	
Protron	PLTV-4250	Power Supply	R03P09-0001I	API5OT35	
Protron	PLTV-4250	Inverter	6632L-0153C	KLS-420CP-A	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Protron	PLTV-4250	Inverter	6632L-0154C	KLS-420CP-B	
Protron	PLTV-4250	T-Con	6871L-0780C	6870C-0080D	
Protron	PLTV-3250	Digital Board	971-1012J-00000	071-13305-00400	YT32MTN0633AC
Protron	PLTV-4250	Main	07113298-R200	F51-670022	
Protron	PLTV-3250	Main	971-1013J-00100	071-13305-00400	F51-670082
Protron	PLTV-3250	Tuner	971-1098H-00100	071-13374-R0100	
RCA	LED65B55R120Q	Power Supply	RE46ZN2120	ER991	
RCA	LED65B55R120Q	Main	3393B1413 V.2	LD.M3393.B	
RCA	LED55C55R120Q	Digital Board	RE3342B058-A1	PL.MS6M30.1B-1-11375	
RCA	LED55C55R120Q	Main	E12110420	T.RSC8.78	
RCA	LED55C55R120Q	Power Supply	RE46ZN1320	ER950	
RCA	LED65B55R120Q	T-Con	55.65.T06.C05	65T06-C00	
RCA	LED65B55R120Q	FRC Board	RE3355R011-A1	LF.M50.C.	
RCA	LED55C55R120Q	T-Con	LJ94-26527B	12YR-S128BMB3-4C4LV0.1	
RCA	LED32B30RQD	Power Supply	RS051S-4T01	3BS0004301GP	
RCA	L40FHD41YX9	T-Con	LJ94-02705E	SYNC60C4LV0.3	
Sampo	LME-17S3	Inverter	QPWBGL9571DG-1	QPWBGL9571DG-1	
Samsung	LNT2632HX/XAA	Inverter	27-D014913	I260B1-12D	
Samsung	LNT4071FX/XAA	T-Con	LN97-01973H	BN81-01324A	40/46/52HHC6LV
Samsung	LNT4071FX/XAA	Main	BN94-01432D	BN41-00904A	BN97-01739D
Samsung	LNT4071FX/XAA	Inverter	SSB400HA20V	BN81-01801A	BN81-01792A
Samsung	LNS5296DX/XAA	Power Supply	BN44-00150A	SIP52	
Samsung	LNT4071FX/XAA	T-Con	LN97-01973H	BN81-01324A	40/46/52HHC6LV
Samsung	LNT4071FX/XAA	Sub	BN94-01442A	BN97-01751A	BN41-00918B
Samsung	LNT4661FX/XAC	T-Con	55.46T02.010	06A83-1A	
Samsung	LNT5265FX/XAA	Inverter	INV52B24ARL	SSB520WA24	
Samsung	LNS5296DX/XAA	Inverter	INVST520B(LL)	INVST520B(LL)	
Samsung	LNT4071FX/XAA	Main	BN94-01432D	BN41-00904A	BN97-01739D
Samsung	LNT5265FX/XAA	Main	BN94-01199F	BN41-00843A	BN97-01415C
Samsung	LNT5265FX/XAA	Inverter	INV52B24ARU	SSB520WA24	
Samsung	UN32EH4003FXZA	Main	BN94-06008A	BN97-05375B	
Samsung	UN32EH4003FXZA	Power Supply	BN44-00554B	PD32GV0.CHS	
Samsung	UN32EH5000FXZA	Power Supply	BN44-00665A	L32GF-DSM	
Samsung	UN32EH5000FXZA	T-Con	BN95-00854A	BN97-06992A	BN41-01938B
Samsung	UN32EH5300FXZA	Main	BN94-06696U	BN41-01812A	BN97-06298N
Samsung	UN40D6000SFXZA	T-Con	BN96-16448A	S128CM4C4LV0.4	
Samsung	UN40D6000SFXZA	Main	BN94-04358H	BN41-01587B	BN97-05206B
Samsung	UN40EH6030FXZA	Main	BN94-05874S	BN97-06807G	
Samsung	UN40EH6030FXZA	T-Con	BN95-00689B	BN97-06770A	
Samsung	LNT5265FX/XAA	Inverter	INV52B24ALU	SSB520WA24	
Samsung	UN50H5203AF	Power Supply	BN44-00772A	L50HF-EHS	
Samsung	UN50H5203AF	Main	BN94-07741D	BN97-08781E	
Samsung	UN50H5203AF	T-Con	55.50T12.C09	50T12-C05	50T12-C05

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Samsung	UN50H5203AFXZA	T-Con	55.50T12.C09	T500HVN05.0	
Samsung	UN50H5203AFXZA	Main	BN94-07741D	BN97-08781E	
Samsung	UN50H5203AFXZA	WIFI	BN59-01174A	WIDT30Q	
Samsung	UN50H5203AFXZA	Power Supply	BN44-00772A	L50HF_EHS	
Samsung	LNS5296DX/XAA	Inverter	INVST520B(RU)	INVST520B(RU)	
Samsung	LNS5296DX/XAA	Inverter	INVST520B(LU)	INVST520B(LU)	
Samsung	LNS5296DX/XAA	Inverter	INVST520B(RL)	INVST520B(RL)	
Samsung	LNS4092DX/XAA	T-Con	LJ94-01218E	400W2C4LV1.5	
Samsung	LNS4041DX/XAA	Inverter	HI40024W21-B	H063426949-A0	
Samsung	LNS4041DX/XAA	T-Con	LJ94-01370D	3240WTC4LV0.5	
Samsung	LNR3228WX/XAA	T-Con	55.31T01.107	T315XW01V5	05A09-1C
Samsung	LN46B650T1FXZA	Power Supply	BN44-00265B	E301536	
Samsung	LN46B650T1FXZA	Main	BN94-02578G	BN41-01149A	
Samsung	LN46B650T1FXZA	Main	BN94-02578G	BN41-01149A	
Samsung	LN46A850S1FXZA	Inverter	LJ97-01807B	SSI460-24C01	INV46N24D
Samsung	LN46A850S1FXZA	Main	BN94-02088E	BN41-01070C	BN97-02500E
Samsung	LN46A850S1FXZA	T-Con	BN81-02129A	2574E	
Samsung	LN40E550F7FXZA	Inverter	LJ97-00207A	SST400-08A01	
Samsung	LN40E550F7FXZA	Main	BN96-23579A	BN97-06963C	BN41-01704A
Samsung	LN40A500T1FXZA	Main	BN94-02257A	BN41-00975C	
Samsung	LN40A500T1FXZA	T-Con	35-D026047	V400H-C03	
Samsung	40PFL7505D/F7	T-Con	LJ94-03287M	S120BM4C4LV0.7	
Samsung	UN40EH6030FXZA	Power Supply	BN44-00552A	PSLF930C04D	
Samsung	LNT5265FX/XAA	Inverter	INV52B24ALL	SSB520WA24	
Samsung	LN32A300J1DXZA	Main	BN96-08996B	BN41-00965B	
Samsung	LN-S4692D	T-Con	BN81-01286A	LJ94-01318B	
Samsung	LN-S4692D	Main	BN94-00963B	BN41-00679D	
Samsung	LN-S4692D	Power Supply	BN97-00588A	BN41-00542A	
Samsung	LN-S4692D	Inverter	120V46W2B rev 14	120V46W2B	
Samsung	LNT4071FX/XAA	Sub	BN94-01442A	BN97-01751A	BN41-00918B
Samsung	LN46B650T1FXZA	Main	BN94-02578G	BN41-01149A	
Samsung	UN60H6203AFXZA	Main	BN94-07727H	BN97-08810A	
Samsung	UN60H6203AFXZA	Power Supply	BN44-00775A	L60H1-EHS	
Samsung	LNS4692DX/XAA	Main	BN94-00963B	BN41-00679D	
Samsung	LNS4692DX/XAA	Power Supply	BN97-00588A	BN41-00542A	
Samsung	LNS4692DX/XAA	T-Con	BN81-01286A	LJ94-01318B	460WSC4LV0.4
Samsung	LNS4692DX/XAA	Inverter	120V46W2B rev 14	120V46W2B	
Samsung	LNS4692DX/XAA	Inverter	120V46W2B rev 14	120V46W2B	
Samsung	LNT4061FX/XAA	Main	BN94-01518F	BN97-01835F	
Samsung	LN26A330J1D	Main	BN96-07895B	BN41-00965A	
Samsung	LN55C630K1FXZA	T-Con	LJ94-03291N	S120APM4C4LV0.4	
Samsung	UN46C6400RFXZA	Main	BN94-03404G	BN41-01438B	
Samsung	LN32A450C1DXZA	Main	BN94-01638D	BN97-01995D	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Samsung	LN46B650T1FXZA	T-Con	LJ94-02852D	2009FA7M4C4LV0.9	
Samsung	LN46B650T1FXZA	T-Con	LJ94-02852D	2009FA7M4C4LV0.9	
Samsung	LNS4051DX/XAA	Power Supply	BN44-00134C	IP-230135A	Bad Inverter
Samsung	LN52A850S1FXZA	Inverter	BN81-02449A	SSI520-28B01-S	LJ97-01809A
Samsung	LN52A850S1FXZA	Inverter	BN81-02448A	SSI520-28B01-M	LJ97-01808A
Samsung	LN-S4692D	Inverter	120V46W2B rev 13	120V46W2B	
Samsung	LN-S4692D	Inverter	120V46W2B rev 13	120V46W2B	
Samsung	LNS4692DX/XAA	Power Supply	BN97-00588A	BN41-00542A	
Samsung	LN46B650T1FXZA	Power Supply	BN44-00265B	E301536	
Samsung	LN46B650T1FXZA	Inverter	LJ97-02094A	SSB460H16V01	
Samsung	LN-S4692D	Inverter	120V46W2B rev 14	120V46W2B	
Samsung	UN55FH6200FXZA	Power Supply	BN44-00499A	PD55AV1-CHS	
Samsung	LNS4092DX/XAA	Main	BN94-00963A	BN97-00964B	NOTE CONNECT
Samsung	UN46C6500VFXZA	T-Con	BN81-04355A	S120APM4C4LV0.4	
Samsung	LN46B500P3FXZA	T-Con	55.46T03.C17	T370HW02 VC	
Samsung	LN52A650A1FXZA	Main	BN94-01666E	BN97-02044G	
Samsung	LN32D405E5DXZA	Inverter	19.31T08.005	INV32T4UB	
Samsung	LN46D550K1FXZA	Inverter	LJ97-02094A	SSB460H16V01	
Sansui	HDLCD4060	Main	A13030745 V.1	T.MS3391.A2C	
Sansui	HDLCD4050	Main	CA70I11311	CMK201B	
Sansui	HDLCD4050	AV Board	CEK677A	x3285	
Sansui	HDLCD4050	T-Con	35-D057146	V315H3-CPE6	
Sansui	HDLCD4060	Power Supply	CEM899A	CCP-3400ST	
Sansui	HDLCD4050	Power Supply	CEK649A	DG-1107A	
Sanyo	DP42647	Main	N4VE	1AA4B10N20000	
Sanyo	DP46848	Power Supply	1AV4U20C38000	FSP270-3PI03A	
Sanyo	DP46848	Inverter	19.46T02.005	4H.V2358.191/A	
Sanyo	DP42648	Inverter	27-D011766-S	I420H1-20B-Slave	
Sanyo	DP42647	Power Supply	1AV4U20C10000	DPS-291AP-1	
Sanyo	DP42648	Power Supply	1AV4U20C17401	DPS-242BP-1A	
Sanyo	DP42648	Inverter	27-D011766-M	I420H1-20B-Master	
Sanyo	DP46819	Power Supply	1AV4U20C38800	B094-501	
Sanyo	DP46819	Main	N7EJ	1AA4B10N22900 A	
Sanyo	DP26648	Inverter	27-D23043	VIT70063.50	
Sanyo	DP32642	Inverter	27-D064525	D064525	
Sanyo	DP42648	Main	N4VK	1AA4B10N21300	
Sanyo	47PFL7422D/37	T-Con	6871L-1320A	6870C-0120C	
Sanyo	DP42648	T-Con	996510010061	V420H1-C07	
Sanyo	DP42647	T-Con	55.42T01.046	T420XW01 V5	0940-0000-1970
Sanyo	DP42647	Inverter	19.26006.223	AUO-19.26006.223	19.26006.223
Sanyo	47PFL7422D/37	Inverter	6632L-0393B	KUBNKM133LB	
Sanyo	47PFL7422D/37	Inverter	6632L-0392B	KUBNKM133LA	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Sanyo	47PFL7422D/37	Main	310432853752	3104.303.50842	
Sanyo	47PFL7422D/37	Power Supply	272217100523	PSC10192J M	
Sanyo	DP42647	Inverter	19.26006.223	AUO-19.26006.223	19.26006.223
Sanyo	DP39E63P39E63-00	T-Con	3E-D078809	V390HJ1-CE1	
Sanyo	DP32648	T-Con	55.06A53.005	T315XW02V9	T260XW02VA
Sanyo	DP32640	Main	1LG4B10Y0880A	N8LA	
Sanyo	DP32640	Power Supply	BK.01109.H01	N0AB2EF00004	
Sanyo	DP46848	Main	N6ELE	1AA4B10N21300	
Sceptre	X32BV-FULLHD	Power Supply	FSP190-4F03	3BS0133617GP	
Sceptre	X32BV-FULLHD	Inverter	19.31T05.001	4H.V2578.021/D	
Sceptre	X505BV-FHD	Main	C12090002	V500HJ1-L01	
Sceptre	X32BV-FULLHD	Main	800-MSD119C-010C	500-MSD119C-010C	
Sceptre	X46BV-1080P	Inverter	19.26006.395	4H.V2358.071/A	
Sceptre	X46BV-1080P	Main	ETV5382	EBD7.780.665	
Sceptre	X46BV-1080P	Power Supply	34.05G02.011	GIPAD14624BAA	PCBADA009-24B
Sceptre	X46BV-1080P	Inverter	19.26006.394	4H.V2358.081/A	
Sceptre	X32BV-FULLHD	T-Con	55.31T05.C01	T315HW01 V0	
Seiki	SE322FS	Power Supply	AY076D-4HF03	AY076D-4HF03	3BS0036914
Seiki	SE322FS	Main	SE322FS	BLT320XVD01.0	
Sharp	LC-62C42U	Inverter	RUNTKA259WJZZ	QKITF0167S1P2	
Sharp	LC-52LE700UN	Power Supply	RUNTKA639WJQZ	PSD-0725	QPWBS0314SNP
Sharp	LC-52LE700UN	T-Con	DUNTKFM08S	XF239	RUNTK4225TP
Sharp	LC-52E77UN	T-Con	CPWBX4023TPXQ	KE789	XE789WJ
Sharp	LC-52D78UN	Main	DUNTKF496FM04	DUNTKF496WE04	KF496
Sharp	LC-52E77UN	Power Supply	RDENCA336WJQZ	DPS-286AP	
Sharp	LC-52D62U	T-Con	CPWBX3520TPZZ	CPWBX3520TPZZ	
Sharp	LC-52D62U	Inverter	RUNTKA261WJZZ	QKITF0168S3P2(6B)	
Sharp	LC-52D43U	Inverter	RUNTKA262WJZZ	QKITF0168S4P2(6B)	
Sharp	LC-50LE650U	T-Con	35-D084088	V420HK1-CS5	
Sharp	LC-50LE650U	LED Driver	27-D083863	C500E06E02A	
Sharp	LC-C5262U	T-Con	CPWBX3520TPZZ	CPWBX3520TPZZ	
Sharp	LC-52D64U	T-Con	CPWBX3829TPXK	XE258WJ	
Sharp	LC-46D78UN	Power Supply	RUNTKA679WJQZ	DPS-207AP	
Sharp	LC-46D78UN	T-Con	DUNTKF466FM04	KF466	
Sharp	LC-46D78UN	T-Con	DUNTKF466FM04	KF466	
Sharp	LC-46D78UN	Main	DUNTKF496FM04	KF496	
Sharp	LC-46D78UN	Power Supply	RUNTKA679WJQZ	DPS-207AP	
Sharp	LC-46D65U	Main	DUNTKE558FM01S	KE558	
Sharp	LC-42SV49U	Inverter	27-D057816	T871028.14	
Sharp	LC-42D72U	Inverter	RUNTKA272WJZZ	MPV8A045	
Sharp	LC-42D62U	Inverter	RUNTKA271WJZZ	MPV8A044	PCPV0047
Sharp	LC-40D78UN	Inverter	RDENC2611TPZZ	IM3869T	
Sharp	LC-39LE440U	Power Supply	9JY0939CTJ01000	FTPL-003	09-39CTJ010-00

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Sharp	LC-39LE440U	Main	9JY0139CTJ01100	1P-0127X00-2010	01-39CTJ011-00
Sharp	LC-50LE650U	Main	9JY0150CTN04100	0150CTN04100	
Sharp	LC-50LE650U	Power Supply	9JY0950CTN04000	FTPL-008	09-50CTN050-00
Sharp	LC-60C52U	Inverter	RUNTKA260WJZZ	QKITF0167S2P2	
Sharp	LC-52D43U	T-Con	CPWBX3796TPZC		
Sharp	LC-52D43U	Inverter	RUNTKA261WJZZ	QKITF0168S3P2(6B)	
Sharp	LC-52D43U	Inverter	RUNTKA262WJZZ	QKITF0168S4P4(6B)	
Sharp	LC-52D43U	Inverter	RUNTKA259WJZZ	QKITF0168S3P2(6B)	
Sharp	LC-52D43U	Inverter	RUNTKA260WJZZ	QKITF0167S2P2	
Sharp	LC-52D43U	Power Supply	RDENCA184WJQZ	LC605-4001CC	
Sharp	LC-52D43U	Terminal Boarc	DUNTKD935FM02	ND935WJ	
Sharp	LC-52D43U	Main	DUNTKD862FM07	XD862WJ	
Sharp	LC-46SB54U	Inverter	RUNTKA384WJZZ	2995313600	
Sharp	LC-32D44U	Power Supply	RUNTKA448WJQZ	QPWBS0204SNPZ (86)	Don't think works
Sharp	LC-46SB54U	Terminal Boarc	DUNTKE208FM01	QPWBNE208WJZZ	
Sharp	LC-46SB54U	Inverter	RUNTKA383WJZZ	2995313500	
Sharp	LC-46SB54U	SMPS Board	RUNTKA317WJQZ	DC-2541-1 A	
Sharp	LC-46SB54U	T-Con	CPWBX3853TPZK	X3853TPZX	
Sharp	LC-46SB54U	Power Supply	RDENCA235WJQZ	DPS-304BP-1	
Sharp	LC-46SB54U	Main	DUNTKE558FM02S	XE558WJ	
SONY	KDL-46V25L1	Tuner	A-1164-341-B	1-869-519-11	
SONY	KDL-52S5100	Inverter	LJ97-02040A	SSB520H20S01	
SONY	KDL-46VL150	Power Supply	1-487-341-11	G7N	
SONY	KDL-46VL150	D1 Board	A-1663-186-E	1-878-620-12	
SONY	KDL-52XBR3	T-Con	LJ94-01397T	520HTC4LV1.0	
SONY	KDL-55EX723	G8 Board	1-474-302-11	DPS-78	
SONY	KDL-32S3000	Power Supply	1-474-052-12	APS-229 G1H	
SONY	KDL-32S5100	Inverter	1-857-267-11	SSI320-8A01	
SONY	KDL-26S2000	B Board	A-1179-491-A	1-869-852-12	
SONY	KDL-55EX720	T-Con	LJ94-03895H	EDL_4LV0.3	
SONY	E600I-B3 LFTRPUBQ	Power Supply	09-60CAP030-00	1P-113B800-1012	
SONY	KDL-55EX800	T-Con	LJ94-03810B	TQL_S120B_960_4LV0.1	
SONY	KDL-55EX720	T-Con	LJ94-03895H	EDL_4LV0.3	
SONY	KDL-46V3000	DF2 Board	A-1253-585-A	1-874-032-12	
SONY	KDL-46V3000	Inverter	LJ97-01154C	SSB460HA24-L	
SONY	KDL-46V3000	DF3 Board	A-1253-586-B	1-873-817-12	
SONY	KDL-46V3000	Power Supply	A-1362-549-C	1-873-813-14	
SONY	KDL-46V3000	Inverter	LJ97-01155C	SSB460HA24-R	
SONY	KDL-55HX800	Main	A-1778-906-A	1-881-636-61	
SONY	KDL-55HX800	LED Driver	LJ97-02929A	SSL550EL-S01	
SONY	KDL-55HX800	Power Supply	1-474-240-11	1-881-893-11	
SONY	KDL-46V3000	TUU2 Boardt	A-1269-502-A	1-728-810-22	
SONY	KDL-46VL150	T-Con	LJ94-02669H	46NU_MB4C6LV0.7	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
SONY	KDL-46V25L1	Inverter	A-1251-295-A Left	PCB2700	
SONY	KDL-32XBR4	Inverter	1-789-795-11	LT320W3S16	
SONY	KDL-40L4000	T-Con	LJ94-02441J	400HAC2LV3.0	
SONY	KDL-40S5100	Power Supply	A-1660-720-A	T6.3AH	1-878-598.11
SONY	KDL-40W4100	Inverter	LJ97-01616A	SSB400W16S01	
SONY	KDL-46XBR5	DF2 Board	A-1253-585-B	1-874-032-12	
SONY	KDL-46EX600	T-Con	LJ94-03500F	TSL-C2LV0.2	
SONY	KDL-46EX600	T-Con	LJ94-03500F	TSL-C2LV0.2	
SONY	KDL-46S2000	Power Supply	A-1144-543-E	1-869-027-12	
SONY	KDL-46S2000	AU Board	A-1192-415-D	1-869-849-15	
SONY	KDL-46S2010	QS Board	A-1153-812-A	1-868-963-11	1-726-916-11
SONY	KDL-46S2010	Inverter	A-1251-295-A Left	A06-126438C	A06-126439C
SONY	KDL-46WL135	AU Board	A-1550-554-A	1-876-856-21	
SONY	KDL-46WL135	FB1 Board	A-1418-995-B	1-873-846-15	
SONY	KDL-46V25L1	T-Con	LJ94-01547D	460HSC4LV3.5	
SONY	KDL-55EX720	LD Board	A-1804-042-A	1-883-300-21	
SONY	KDL-55EX720	LD Board	A-1804-042-A	1-883-300-21	
SONY	KDL-46V25L1	AU Board	A-1184-344-A	1-871-231-11	
SONY	KDL-46V25L1	Inverter	A-1251-295-A Left	PCB2701	
SONY	KDL-46V25L1	Power Supply	A-1207-096-C	1-871-504-11	
SONY	KDL-52W4100	BU Board	A-1547-091-A	1-876--561-13	A1506072C
SONY	KDL-52XBR2	Signal Board	A-1252-228-A	1-871-244-13	
SONY	KDL-46V25L1	Inverter	A-1251-295-B Right	PCB2698	
SONY	KDL-52S5100	Inverter	LJ97-02040A	SSB520H20S01	
SONY	KDL-46VL150	D2 Board	A-1663-190-E	1-878-621-12	
SONY	KDL-52S5100	Inverter	LJ97-02039A	SSB520H20S01	
SONY	KDL-52S5100	Inverter	LJ97-02039A	SSB520H20S01	
SONY	KDL-52XBR3	Power Supply	A-1231-579-A	1-870-864-12/13	
SONY	KDL-46V25L1	Inverter	A-1251-295-B Right	PCB2699	
SONY	KDL-52XBR3	T-Con	LJ94-01397T	520HTC4LV1.0	
SONY	KDL-52XBR3	D4 Board	A-1208-983-F	1-870-865-11/12	
SONY	KDL-52XBR3	D5 Board	A-1208-985-A	1-870-866-11/12	
SONY	KDL-40R450A	Main	1-895-371-11	ZY100138A	
SONY	KDL-40R450A	Main	1-895-371-11	ZY100138A	
SONY	KDL-40R450A	Power Supply	1-474-487-11	APS-349	
Sylvania	LC320SL1 TH1	Inverter	A01FKM1V-001-IV	A01F4F01031A	
Sylvania	LC320SL1 TH1	Power Supply	A01FKMPW	BA94F0F01025A	
Toshiba	32AV500U	Inverter	75012526	PB-071109F	JLS-05-32EI
Toshiba	42HL167	Seine Board	75007224	PE0316A	
Toshiba	52RV530U	Inverter	LJ97-01648A	SSI520-24A01 LU	
Toshiba	32AV500U	Power Supply	75011297	9OC1450200	PK101V0550I
Toshiba	37E200U	Main	75017703	431C2751L21	
Toshiba	42HL167	Main	75006715	PE0349A-1	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Toshiba	42HL167	Inverter	27-D011811-S	VIT70023.81	
Toshiba	42HL167	T-Con	35-D014934	FHD-CM	
Toshiba	52XF550U	Inverter	LJ97-01497B	SS1520HB24	
Toshiba	52XF550U	Inverter	LJ97-01498B	SS1520HB24	
Toshiba	52XF550U	Inverter	LJ97-01499B	SS1520HB24	
Toshiba	52RV530U	Inverter	LJ97-01647A	SSI520-24A01 LL	
Toshiba	46L5200U1	Main	75031308	431C4R51L13	HDMI1 ONLY
Toshiba	52RV530U	Inverter	LJ97-01645A	SSI520-24A01 RL	
Toshiba	52RV530U	Sub Power	75011243	PE0563A	
Toshiba	52RV530U	Power Supply	75011257	PE0569A	
Toshiba	52RV530U	Main	75012467	PE0541A	
Toshiba	52RV530U	T-Con	LJ94-02279H	FHD60C4LV0.2	
Toshiba	42HL167	Low B board	75006714	PE0307E	
Toshiba	42HL167	Inverter	27-D011811-M	VIT70023.80	
Toshiba	40E200U1	T-Con	LJ94-02780B	SYNC60C4LV0.3	
Toshiba	52XF550U	Inverter	LJ97-01500B	SS1520HB24	
Toshiba	37HL67S	Seine Board	75009033	PE0434A	
Toshiba	37HL67S	T-Con	55.06A69.001	T370XW02 V5 CB	06A69-1A
Toshiba	42HL167	Power Supply	75006713	PE0306E	
Toshiba	37HL67S	Low B board	75008943	PE0439B	
Toshiba	37HL67S	Main	75008928	PE0440A-1	
Toshiba	37HL67S	Power Supply	75008948	PE0438A	
Toshiba	55SL412U	T-Con	LJ94-16111F	JPN_S128BM4C4LV0.2	
Toshiba	52RV530U	Inverter	LJ97-01646A	SSI520-24A01 RU	
Toshiba	32AV500U	T-Con	19100110	MDK336V-0	
Toshiba	37HL67S	Inverter	996510006928	4H.V1448.481/C1	0940-0000-1900
Vizio	VW47LFHDTV10A	Inverter	19.26006.392	4H.V2358.071/A	
Vizio	VX32LHDTV10A	Inverter	19.26006.320	4H.V0708.501/D6	
Vizio	L32HDTV10A	T-Con	55.31T01.095	T315XW01V5	T260XW02V2
Vizio	VA26LHDTV10T	Main	CBPF82MKZ5	715T3000-1	
Vizio	L32HDTV10A	Main	3320-0102-0150	0171-2272-1973	
Vizio	VA26LHDTV10T	Inverter	INTV8GAAMQA8	715G3335-P01-000-003D	
Vizio	VW46LFHDTV10A	Power Supply	0500-0408-0530	4H.B0940.011/C1	B094-101
Vizio	E601I-A3 LFTRNWAN	T-Con	RUNTK5261TPZC	CPWBX5261TPZC	
Vizio	VO37LFHDTV10A	Main	3637-352-150	0171-2272-2634	
Vizio	VO420E LAQAECBL	Main	3642-0762-0150	0171-2271-3060	
Vizio	VO420E LAQAECBL	T-Con	55.42T03.C11	T420HW04 V0	
Vizio	E320VL	Power Supply	0500-0412-1010	PLHC-A942A	
Vizio	E420-A0 LAQKNRGP	Power Supply	0500-0614-0300	PSLF131401M	
Vizio	E420-A0 LATKNRFP	Main	3642-1792-0150	0171-2271-5032	
Vizio	E420VL	Power Supply	0500-0412-1030	3PCGC10017A-R	
Vizio	E420VO	Main	3642-0972-0150	171-2271-3274	
Vizio	E422VA	T-Con	6871L-2045L	6870C-0310C	

LCD/LED

Make	Model	Type	Part#	Board#	Board#2
Vizio	E320VL	Main	3632-1122-0150	0171-2271-3293	
Vizio	E422VA	T-Con	6871L-2045L	6870C-0310C	
Vizio	XVT323SV	Power Supply	0500-0612-0010	PLDC-A951A	
Vizio	XVT323SV	PC Board	3632-0022-0147	171-2372-24	
Vizio	L42HDTV10A	Inverter	6632L-0372A	PW-CC42B0-S	
Vizio	L32HDTV10A	Inverter	19.26006.166	4H.V1448.291/B1	
Vizio	L32HDTV10A	Power Supply	0500-0502-0102	0469D03	
Vizio	E370VL	Main	3637-0562-0150	0171-2271-3274	
Vizio	E370VL	Power Supply	0500-0412-1020	PLHD-A943A	
Vizio	VO420E LAQAECBL	Power Supply	0500-0407-0880	DPS-260JP-2A	
Vizio	L42HDTV10A	Inverter	6632L-0371A	PW-CC42B0-M	
Vizio	E550I-A0-LATAOQAP	WIFI	0980-0140-0640	0171-2271-4903	
Vizio	E550I-A0-LATAOQAP	Main	3655-0642-0150	0171-2271-4903	
Vizio	VA26LHDTV10T	Power Supply	PWTV9GAAQQ2	715G3418P02W30003M	
Vizio	VA26LHDTV10T	Power Supply	ADTV81324SA1	715T3003-1	
Vizio	E550I-A0-LATAOQAP	Power Supply	0500-0605-0320	FSP196-3PSZ01	
Vizio	L32HDTV10A	Inverter	19.26006.166	4H.V1448.291/B1	
Vizio	E700I-B3	T-Con	072-0001-4809	RUNTK5489TP	
Vizio	L32HDTV10A	Video Box	3320-0012-0187	0171-1412-0320	
Westimghouse	LTV-32W6HD	Power Supply	4900214080	LT32B-2	2970053301
Westimghouse	LTV-32W6HD	Main	5600110532	LT32CGN	Two Available
Westimghouse	SK-32H590D	Main	55.71C01.A01G	07278-1	
Westimghouse	LTV-32W6HD	Main	5600110532	LT32CGN	Two Available
Westimghouse	CW50T9YW	Power Supply	MIP500HW		
Westimghouse	LTV-32W6HD	Inverter	27-D004821	VIT70002.6	I320B1-24-V04
Westimghouse	LTV-32W6HD	Main	5600600039	LTE32E	
Westimghouse	SK-32H590D	Inverter	27-D014496	I260B1-12C	
Westimghouse	LTV-32W6HD	T-Con	35-D004737	V320B1-C	
Westimghouse	SK-32H590D	Power Supply	4900254680	LT27B-2	
Westimghouse	SK-32H590D	DVD Drive	5041601300	KDRM081	
Westimghouse	SK-32H590D	T-Con	35-D019163	V260B1-C01	
Westimghouse	SK-32H590D	T-Con	35-D020345	V260B1-C01	
Zenith	L27W46	T-Con	35-A27C0216	V270W1-C	