





Getting Started



SavvyLevel for Caravan



SavvyLevelRV for Motorhome/RV

SavvyLevel™ or SavvyLevelRV™ are free apps 'one of which' needs to be installed on your smart phone so that it can communicate with the SavvyLevel device installed in your Caravan, motorhome or other RV. SavvyLevel uses Bluetooth® low energy connection.

For use with:

- iPhone, iPad 4 or newer models
- Android[™] v4.3.1 (Jelly Bean) or later.

SavvyLevel apps are available on the App Store and Google Play™. Search for either 'SavvyLevel' (for a caravan) or 'SavvyLevelRV' (for a motorhome or other RV), then download and install the app.





It's as easy as 1, 2, 3



Make sure your SavvyLevel device is powered and in range.



Launch your chosen app.



Tap 'Connect device' and select 'Savvy3' from the menu.

User Guides

Download the latest User Guides from www.savvylevel.com/savvylevel-user-manual



iPhone and iPod are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Android and Google Play are trademarks of Google Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All other trademarks are trademarks of their respective owners.