

The following instructions are the recommendations that should be followed when using Aacer CourtKleen™ Daily and Intensive cleaners.

Daily Care

The following are the instructions that should be followed when doing daily cleaning of your sport floor.

1. The floor should be swept with the Aacer MagicFiber pad.
2. Combine 4 parts water and 1 part Aacer CourtKleen™ Daily cleaner.
3. There are 2 ways to apply the cleaner to the floor.
 - a. The first is to soak several Aacer MicroFiber pads or large white cotton towels in the bucket. Wring out the MicroFiber pads or towels until damp.
 - b. The second is to pre-mist the floor using the Aacer CourtKleen™ Applicator. This should only be done in small sections so the cleaner does not sit on the floor for more than 5 minutes.
4. Next attach the damp MicroFiber pad to the CourtKleen™ mop or wrap a damp towel around a broom and tack the floor until it is completely free of dirt and oil. To prevent redeposit of dirt and oil, change the MicroFiber pad every 1/3 of the floor or as needed. If using a towel, refold the towel using clean sides and replace with a new damp towel until the floor is clean.

Intensive Cleaning

The following are the instructions that should be followed when doing a once a month heavy cleaning or cleaning a floor before it is screened and recoated.

1. To prepare the floor, remove all caked on mud, chewing gum and other debris from the floor. Sweep using the Aacer MagicFiber pad and then vacuum floor to make sure that all debris is removed from any spaces between the boards. Pay special attention to corners.
2. Combine 4 parts water and 1 part Aacer CourtKleen™ Intensive cleaner.
3. There are 2 ways to apply the cleaner to the floor.
 - a. The first is to soak several Aacer MicroFiber pads or large white cotton towels in the bucket. Wring out the MicroFiber pads or towels until damp.
 - b. The second is to pre-mist the floor using the Aacer CourtKleen™ Applicator. **Do not exceed more than 5 minutes with the solution on the floor. Also be aware of any areas that the solution may run down under the floor. In these areas the solution should be removed immediately.**
4. Next attach the damp MicroFiber pad to the CourtKleen™ mop or wrap a damp towel around a broom and tack the floor until it is completely free of dirt and oil. To prevent redeposit of dirt and oil, change the MicroFiber pad every 1/3 of the floor or as needed. If using a towel, refold the towel using clean sides and replace with a new damp towel until the floor is clean.
5. Repeat steps 3-4 in each area until the entire floor has been cleaned.
6. **NOTE:** For stubborn surface marks, dirt and shoe marks, use a moderately abrasive nylon pad or sponge moistened with diluted CourtKleen™ Intensive solution and scour the area manually until the spot is removed. Follow with a clean water rinse on the scrubbed area.
7. Always rinse the floor by damp mopping with clean water and a clean mop until the rinse water is clean or use tack towels with clean water.
8. Clean the floor again using CourtKleen™ Daily cleaner, following the same cleaning procedure described above (steps 2-4). Since CourtKleen™ Daily cleaner does not leave a residue, no clear water rinse is needed after this step.
9. **NOTE:** The two cleaners are specifically formulated to remove different types of contaminants from the floor and may not be combined into a single treatment.

Alternate Application Method of Intensive Cleaning

1. Combine 4 parts water and 1 part Aacer CourtKleen™ Intensive cleaner.
2. Soak string mop in the solution and wring excess out.
3. Mop the floor paying special attention to corners. Re-soak and wring mop frequently. Mop until the entire floor has been cleaned.
4. Always rinse the floor by damp mopping with clean water and a clean mop until the rinse water is clean or use tact towels with clean water. Again, pay special attention to corners.
5. Clean the floor again using CourtKleen™ Daily cleaner, following the same cleaning procedure described above (steps 2-4). Since CourtKleen™ Daily cleaner does not leave a residue, no clear water rinse is needed after this step.
6. **NOTE:** The two cleaners are specifically formulated to remove different types of contaminants from the floor and may not be combined into a single treatment.

Cleaning of Synthetic Surfaces

To clean our **MP Sport** and **MP Trax** surfaces, the procedures for the Daily Care above should be followed to maintain the floors surface. The following steps can be used in addition to the steps mentioned above.

1. An auto scrubber can be used in place of the MagicFiber pads.
2. Make sure that the solution tank is thoroughly rinsed out before adding Aacer CourtKleen™ Daily cleaner.
3. Mixture ratio is still 4 parts water and 1 part Aacer CourtKleen™ Daily cleaner.
4. Use white or blue floor pads with a light head pressure. Too aggressive of a pad will cause premature wearing of the finished surface.
5. Do not allow the auto scrubber to stay active in one location for an extended period of time. This could cause premature wear of that spot.
6. Do not use a pad that has been used on other floors in the facility.
7. Make sure that the squeegees are in good operation condition to pick up all of the solution as you clean.

For our **MP Elite** surfaces, the following additional procedures need to be followed to properly clean and maintain this product.

1. The mixture ration change to 8 parts water and 1 part Aacer CourtKleen™ Daily cleaner.
2. Special attention should be made to make sure that the solution is not allowed to run into any of the seams. This should be removed immediately.

General Maintenance Tips

1. Do not use cleaning products on newly installed floors for at least 30 days.
2. Use entrance mats at all doorways and keep them vacuumed.
3. Always clean up liquid spills immediately.
4. Avoid scratching the floor when moving equipment.
5. Only clean athletic shoes should be allowed on the floor.