

User instructions

Before use. Seek advice and familiarise yourself with the equipment. Do not use any equipment that is damaged. Please report any damage or unserviceability. Always fit the 2-part lid before starting the extraction.

In Use. Using the fittings provided, bolt the body of the extractor to the platform to stabilise it. Position the frames in the stainless-steel rack to 'balance the rotor'.

After use. Unlike many extractors, this one does not have a ball-bearing below the shaft. It can be taken apart by removing the 4 wing-nuts on the top rim and lifting the rotor out. Do not use any abrasive or chemical cleaners.

Washing.

1. Leave inverted to drain in a warm place.
2. COLD WATER wash using a hand-held spray (or high-pressure washer outdoors).
3. Repeat until clean, finishing off with warm water.

* * Warm water melts the wax over the honey, making it difficult to dissolve. Do not put the extractor out for the bees to clean! This spreads disease and encourages robbing.

View this good video = <http://www.youtube.com/watch?v=wK4nOdh-BWQ>

Please return equipment as soon as you have finished.

SCBKA Committee.